


# INSTALLATION INSTRUCTIONS

## STAND-OFF FILTER RACK KIT

#8G05008



NAHA001TK1

BILL OF MATERIAL	
DESCRIPTION	QTY
FILTER (20 x 25 x 1)	1
FILTER RACK	1
SCREWS	4



## INSTALLATION PROCEDURE

1. To install the *Stand-Off Filter*, cut a hole in the side of the furnace using the embossed angles located on the sides of the Furnace. SEE FIGURE 1



2. Center the filter rack on the side panel flush with the bottom edge of the furnace.
3. Mark the holes and drill with a 9/64 drill bit.
4. Fasten filter rack in place with sheet metal screws provided. SEE FIGURE 2
5. Connect return duct to filter rack, and slide filter into rack and check air flow on unit. SEE FIGURE 3




FIGURE 3

25-21-58