


**Parts List for BHA180MA, BHA180SA, BHA240MA, BHA240SA
HBA180MA, HBA180SA, HBA240MA, HBA240SA**

PARTS ILLUSTRATION

See next page for parts list.

Illustration is for reference only,
your unit may differ from the
one shown.



38-11-08

Replacement Parts List

KEY NO.	DESCRIPTION	PART NUMBER	BHA180MA HBA180MA	BHA180SA HBA180SA	BHA240MA HBA240MA	BHA240SA HBA240SA
1	Coil, Evaporator	1096414	1	1		
1		1096375	-	-	1	1
2	Pan, Drain	1097788	1	1	1	1
3	Manifold Asy, Evap (Lower)	1096395	1	1		
3		1096380	-	-	1	1
4	Manifold Asy, Evap (Upper)	1096394	1	1		
4		1096379	-	-	1	1
5	Distributor	1096384	2	2	2	2
6	Valve, Expansion	1096407	2	2		
6		1096385	-	-	2	2
7	Motor, Blower 460/3 5 Hp	1071520	1	-	1	
7	575/3 5 Hp	1071519	-	1	-	1
8	Pulley, Motor	1097240	1	1	1	1
9	Belt	1096405	1	1		
9		1096381	-	-	1	1
10	Pulley, Blower	1096403	1	1		
10		1096382	-	-	1	1
11	Bearing	1164322	2	2	2	2
12	Isolator, Bearing	1164316	2	2	2	2
13	Shaft	1164321	1	1	1	1
14	Wheel, Blower	1164319	1	1	1	1
15	Blower, Evap ((Includes Key No. 11,12,13,14,B,C)	1096353	1	1	1	1
16	Filter, Air 18X24X1	1096420	8	8	8	8
17	Plug, Drain Pan	1083241	1	1	1	1
A	Cover, Top	1096300	2	2	2	2
B	Housing, Blower (W/Bearing Brackets)	1164317	1	1	1	1
C	Panel, Cutoff	1164318	1	1	1	1
D	Key, Wheel	1164320	1	1	1	1
E	Panel, Access	1097791	4	4	4	4
F	Post, Center	1096319	2	2	2	2
G	Panel, Outlet Air	1096368	1	1	1	1
H	Post, Inlet Corner	1097794	2	2	2	2
J	Panel, Top (Air Inlet)	1096304	1	1	1	1
K	Panel, Top (Side)	1096376	1	1	1	1
L	Panel, Top (Blower End)	1096424	1	1	1	1
M	Panel, Top (Side)	1096371	1	1	1	1
N	Panel, Top (Center)	1096306	1	1	1	1
)(	Bracket, Hanger	1096378	4	4	4	4
)(	Manual, Parts	508041301	1	1	1	1
)(	Manual, Installation/Operation	508011001	1	1	1	1